

Section 8:

Rebuilding the Shocks

Follow these steps to rebuild your trucks shocks.

Required Tools:



Needlenose Pliers



Shock Oil
(Part #5423)



Section 8:

COMPLETE!

Your shocks are now ready to be installed on to your Monster GT.

Shock Tuning Tip

Adding or removing pre-load clips will change the ride height of your truck. Add clips to raise the truck. This will help the truck climb over larger objects and help prevent the truck from bottoming out on landings. Removing clips will lower the truck and its center of gravity and reduce body roll.



Team Associated Silicone Shock Oil!

Available from Team Associated is the 100% Pure Silicone Shock Oil.

- 5420 - Silicone Shock Oil, 10wt
- 5421 - Silicone Shock Oil, 20wt
- 5422 - Silicone Shock Oil, 30wt
- 5423 - Silicone Shock Oil, 40wt
- 5425 - Silicone Shock Oil, 80wt
- 5427 - Silicone Shock Oil, 15wt

- 5428 - Silicone Shock Oil, 25wt
- 5429 - Silicone Shock Oil, 35wt
- 5435 - Silicone Shock Oil, 50wt
- 5436 - Silicone Shock Oil, 60wt
- 5437 - Silicone Shock Oil, 70wt



Team Associated Monster GT Spring Set!

Also available is the Monster GT Spring set. Use the chart below to find the spring best suited to your terrain.



AE Part Number	Spring Color	Spring Rate	Relative Stiffness
25062	Blue (Std)	4.40 lb./in	Softest
25063	Gold	5.10 lb./in	
25064	Red	5.95 lb./in	
25065	Copper	6.90 lb./in	Stiffest