



**Follow these instructions to help prevent the spur gear from rubbing on the A-arm mount.**

The Stealth assembly instructions tell you to install the #7669 spacer onto the drive shaft. To prevent the spur gear from rubbing, install the #3911 shim where shown.

First install one #3911 shim and then one #7669 spacer, then put the two transmission halves together. This spacer moves the drive shaft to the left and stops the spur gear from rubbing on the A-arm mount.