

#7183 Sway Bar Set - Pro Rally Supplement

7183 Sway Bar Rod End

7183 Sway Bar Pivot Cap

7183 Sway Bar Stud

7.5mm

#1596 thread lock

7183 Sway Bar Pivot Ball

7183 Sway Bar (2.0 - Front) (1.8 - Rear)

25225 3 x 3mm Set Screw

NOTE:
Mount swaybar ball ends flush with ends of sway bar.

BUILD x4

7183 2 x 6mm SHCS

NOTE:
Tighten the two socket head screws while still allowing free movement of the sway bar link.

NOTE:
Loosen the four button head screws holding the top of the gear case in place in order to install the sway bar. Re-tighten screws once the sway bar is in place.

NOTE:
Snap sway bar ends into links.

25225 3 x 3mm Set Screw

NOTE:
Do not overtighten set screws, the sway bar should be able to move freely.

NOTE:
Make sure the suspension travels freely when Sway Bars are installed. Adjust the sway bar stud to allow for clearance around the drive shafts and linkages. Everything should be able to move freely and with no obstruction.