

## **:: Threading your Shock Cap/Body**

To avoid cross threading your shock cap onto the shock body, follow these steps:

- 1) Place the cap onto the shock body.
- 2) Rotate the cap counter-clockwise until you feel the cap "drop" onto the threads.
- 3) Slowly rotate the cap clockwise to tighten the cap onto the shock body.

