

:: 91385 Arm Mount Inserts for RC10B5 and RC10B5M

NOTE:

The optional arm mount inserts (91385) are marked based on the effect it produces.

The arrows point in for the D-mount inserts.

The C-mount inserts are labeled with degrees toe and degrees anti-squat (respectively).
So a "3+1" is 3 deg toe and 1 deg anti-squat.

Some mounts are right/left only and are denoted with an "R" or "L" where necessary. Based on driver's side position.

The toe/anti-squat numbers should point up in the arm mount so you can read them from the top.

