

## #92256 RC10B74 Rear Shock Tower 31mm V2



### ATTENTION:

This B74 31mm V2 shock tower is lower than the B74 stock shock tower. To run this shock tower with the correct amount of droop and up-travel, you should start with one of the following two options:

1. **Remove all external** shock limiters the **add 2mm of internal** shock limiters. Use Long shock eyelets for a baseline setup.
2. Use #91619 3x27.5mm Shock Shafts (V2), TiN or #91620 FT 3x27.5mm Shock Shafts (V2), Chrome with Long shock eyelets for a baseline setup.