CARBURETOR RESTRICTOR


for the OSMax

#7712 (silver) .190" #7713 (blue) .180" #7714 (black) .170"









3. Add standard wire ties where shown.

4. Make sure wire tie goes all the way to corner of boot as shown.