

1:10 Scale 4WD Electric Off Road  
Competition Buggy Kit



# TEAM ASSOCIATED



1:10 Scale 4WD Electric Off Road Competition Buggy Kit Manual

#90051 RC10B84D Off Road Buggy Team Kit



CHAMPIONS *by* DESIGN

[AssociatedElectrics.com](http://AssociatedElectrics.com)

# TEAM ASSOCIATED

## ⚙️ Introduction

Thank you for purchasing this Team Associated product. This assembly manual contains instructions and tips for building and maintaining your new vehicle. Please take a moment to read through the manual and familiarize yourself with the steps. We are continually changing and improving our designs; therefore, actual parts may appear slightly different than the illustrations. New parts will be noted on supplementary sheets located in the appropriate parts bags.

Check each bag for these sheets before you start to build.

Check [www.rc10.com](http://www.rc10.com) for the latest versions of our instruction manuals.

## ⚙️ RC10B84D Features

- Molded Height-Adjustable Gearboxes Front and Rear with Additional +2 Rear Gearbox for High-Grip Conditions
- Long-Arm Suspension Geometry: improves grip and predictability in all conditions
- Optimized Steering Bellcranks and Rack: improved bumpsteer control at all ride heights
- Chassis Bracing: Fine tune chassis flex characteristics with upper and lower chassis bracing front and rear
- Standard and HRC (High Roll Center) Rear Hubs Included
- Insert adjustable caster block with 0, +/-1, and +/-2 degree inserts included
- Forward and Back Motor Positions: used for further weight bias adjustment
- Highly Adjustable Battery Holder with Thumb Tabs: allows for easy battery removal and fine tuning of weight bias
- 2.5mm Thick Tapered 7075-T6 Aluminum Chassis with 10 Degrees of Kickup and Improved Departure Angle
- (90050 Only): Decoupled Slipper Clutch Included
- (90051 Only): Molded Ring and Pinion Gears Included
- Aluminum Center-Mounted Servo Mount
- Two heights Included for Rear Wing Mount
- 7-inch Rear Wing
- Low-Profile Body
- Shock Tower Covers Front and Rear
- 3.5mm Turnbuckles and Ballcaps
- 13mm Big-Bore Shocks

## ⚙️ Additional

Your new RC10B84 Kit comes unassembled and requires the following items for completion (refer to [AssociatedElectrics.com](http://AssociatedElectrics.com) for suggestions):

- R/C two channel surface frequency radio system
- AA-size batteries for transmitter
- Electronic Speed Control ("ESC")
- Steering servo
- R/C electric motor
- Pinion gear, size determined by type/turn or kV of motor
- Battery charger (a peak detection charger, or LiPo compatible charger)
- 2 cell LiPo battery pack
- Polycarbonate specific spray paint
- Cyanoacrylate glue ("CA") (#1697)
- Thread locking compound (#1596)
- Tires and Inserts, Fronts and Rears

## ⚙️ Other Helpful Items

- Silicone Shock Fluid (Refer to [AssociatedElectrics.com](http://AssociatedElectrics.com) for complete listings)
- FT Body Scissors (#1737)
- FT Hex/Nut Wrenches (#1519)
- FT Universal Tire Balancer (#1498)
- FT Dual Turnbuckle Wrench (#1114)
- FT Body Reamer (#1499)
- Needle Nose Pliers
- Calipers or a Precision Ruler
- Green Slime shock lube (#1105)
- Shock Pliers (#1681)
- FT Ballcup Wrench (#1579)
- Soldering Iron
- Wire Cutters
- Hobby Knife

Associated Electrics, Inc.  
21062 Bake Parkway  
Lake Forest, CA 92630



Customer Service  
Tel: 949.544.7500  
Fax: 949.544.7501

**Hardware - 1:1 Scale View**

**Button Head (bhcs)**

	2x4mm (31510)
	2.5x5mm (31519)
	2.5x6mm (31520)
	2.5x8mm (31521)
	2.5x10mm (31522)
	3x4mm (91158)
	3x5mm (31530)
	3x6mm (31531)
	3x8mm (31532)
	3x10mm (25211)
	3x12mm (89202)
	3x14mm (25187)
	3x16mm (89203)
	3x18mm (2308)
	3x20mm (25188)
	3x22mm (25189)
	3x24mm (89204)
	3x30mm (91478)

**Flat Head (fhcs)**

	2x3mm (91743)
	2.5x8mm (31472)
	3x5mm (31540)
	3x6mm (31541)
	3x8mm (25201)
	3x10mm (25202)
	3x12mm (25203)
	3x14mm (89208)
	3x16mm (25204)
	3x18mm (89209)

**LP Socket Head (lp shcs)**

	3x6mm (41089)
	3x8mm (41096)
	3x10mm (41090)
	3x22mm (41095)
	3x24mm (41097)

**Set Screws**

	3x2.5mm (31500)
	3x3mm (25225)
	3x6mm (81257)
	3x10mm (4671)
	3x20mm (91737)
	4x5mm (25226)

**Cap Head (shcs)**

	1.6 x 5mm (91611)
--	-------------------

**Nuts (lock/plain)**

	M3 Nut (91477)
	M3 Alum. Locknut, Blue (31550)
	M3 Locknut, Black (25215)
	M3 Locknut w/Flange (25612)
	FT 3mm Locknuts, Blue (25392)
	M4 Locknuts: Serrated Steel LP (91150)
	Serrated Steel (Silver) (91826)
	FT Aluminum (Blue) (31551)
	Serrated Aluminum (Black) (91738)

**Ball Bearings**

	4x7x2.5mm (31732)
	5x8x2.5mm (31400)
	5x10x4mm (91560)
	5x10x4mm flanged (92324)
	5x12x4 (91567)
	10x15x4 (91563)
	12x18x4 (92544)

**Ballstuds**

	HD, short neck 4mm (32041)
	Ti HD, short neck 4mm (32095)
	HD, short neck 6mm (32042)
	Ti HD, short neck 6mm (32096)
	HD, short neck 8mm (32040)
	Ti HD, short neck 8mm (32097)
	HD 6mm (91047)
	Ti HD 6mm (91751)
	HD 8mm (91048)
	Ti HD 8mm (91752)
	HD 10mm (91049)
	Ti HD 10mm (91753)

**Shims and Washers**

	5.5x0.5mm (31381)
	5.5x1.0mm (31382)
	5.5x2.0mm (31383)
	3x8mm Washer (89218)

**Notes:**

## Table of Contents

1.....	Cover	15.....	Turnbuckles Build Bag 8
2.....	Introduction	16.....	Center Differential Build Bag 9
3.....	1:1 Hardware “Fold Out”	17.....	Anti-Roll Bars Build Bag 10
4.....	Table of Contents	17.....	Shocks Build Bag 11
5.....	Chassis and Steering Build Bag 1	20.....	Electronics, Wheels, Body Build Bag 12
7.....	Suspension Arms Build Bag 2	22.....	Tuning Tips
8.....	Front / Rear Gear Differentials Build Bag 3	24.....	Setup Sheet “Kit Setup”
8.....	Front / Rear Gearbox Build Bag 4	25.....	Setup Sheet “Blank”
11.....	Shock Tower Build Bag 5	26.....	Back Cover
13.....	Caster and Steering Block Build Bag 6		
14.....	Rear Hubs Build Bag 7		

## Notes



This symbol indicates a special note or instruction in the manual.



This symbol indicates the number of the same part that is required.



This symbol indicates the order within a step to assemble parts.



This symbol indicates there are optional FT parts available



This symbol indicates a Racers Tip.



This symbol indicates where Thread Lock Adhesive should be applied. \*not included



This symbol indicates where Diff Fluid should be applied.



This symbol indicates where Shock Fluid should be applied.



This symbol indicates where FT Silicone Grease should be applied. \*not included



This symbol indicates where FT Diff Lube should be applied. \*not included



This symbol indicates where Black Grease should be applied.




This symbol indicates where Green Slime can be applied. \*not included




There is a 1:1 hardware foldout page in the front of the manual. To check the size of a part, line up your hardware with the correct drawing until you find the exact size. Each part in the foldout has a number assigned to it for ordering replacement parts.


**:: Bag 1 - Step 1**




**:: Bag 1 - Step 2**




**:: Bag 1 - Step 3**




Bag 1 - Step 4




Bag 1 - Step 5




Bag 1 - Step 6





**:: Bag 1 - Step 7**





**:: Bag 2 - Step 1**




**:: Bag 2 - Step 2**



**:: Bag 2 - Step 3**




**Bag 3 - Step 1**




Build x2 (1 front, 1 rear)

**Bag 3 - Step 2**



**Bag 4 - Step 1**




**Bag 4 - Step 2**



**92264**  
FT CVA  
cup, center,  
aluminum

**92215**  
Center CVA  
input coupler



**BLACK GREASE #9588**

**92218**  
Center CVA  
bones, 64mm

**91438**  
CVA pin



**92372**  
FT Lightweight  
driveline center  
kt

**92324 x2**  
5x10x4mm  
flanged  
bearing

**92216**  
CVA cup, center,  
aluminum



**92543**  
B84 Pinion  
gear, molded

**92513**  
B84 Diff pinion  
height insert,  
0


Number shown on the side of the insert after insertion should match the diff height desired.  
Kit setup: "0"




**Bag 4 - Step 3**

**25226**  
4x5mm  
Set screw

**THREAD LOCK #1596**



**92143**  
Diff pinion  
gear shim



**Bag 4 - Step 4**

**92139 x2**  
Diff outdrive  
shims

**91563 x2**  
10x15x4mm  
bearing

**92513 x2**  
B84 Diff  
height inserts,  
(kit setting 0)



Start by shimming the diff with one shim on either side of the diff. If the diff is tight when inserted into the gearbox, remove one shim from the ring gear side and add it to the diff case side.




**92510**  
B84 FT  
Carbon front  
gearbox

**89202 x4**  
3x12mm  
BHCS


**92509**  
B84 Front  
gearbox,  
upper



Take extra care not to strip these screw holes out. Stripping the plastic will result in premature failure.




**:: Bag 4 - Step 5**



**92512**  
B84 FT  
Carbon rear  
gearbox

**92511**  
B84 Rear  
gearbox,  
lower



**:: Bag 4 - Step 6**



Kit Setting


**92541**  
B84 Arm  
mount backing  
plate

**92540**  
B84 Arm  
mount, D

**92525**  
B84 Rear  
bumper

**25188 x2**  
3x20mm  
BHCS

**92014 x2**  
Arm mount  
inserts, 0



**:: Bag 4 - Step 7**



**92264**  
FT CVA  
cup, center,  
aluminum

**91438**  
CVA barrel



**92215**  
Center CVA  
input coupler


**91438**  
CVA pin

**92216**  
CVA cup, center,  
aluminum

**92324 x2**  
5x10x4mm  
flanged  
bearing

**92543**  
B84 Pinion  
gear, molded



**92513**  
B84 Diff pinion  
height insert,  
1



**92372**  
FT Lightweight  
driveline center  
kt

Number shown on the top and bottom of the rear insert should match the diff height desired.  
Kit setup: "1"


**:: Bag 4 - Step 8**



**:: Bag 4 - Step 9**




92512  
B84 FT Carbon rear gearbox




Start by shimming the diff with one shim on either side of the diff. If the diff is tight when inserted into the gearbox, remove one shim from the ring gear side and add it to the diff case side.

Take extra care not to strip these screw holes out. Stripping the plastic will result in premature failure.


**:: Bag 4 - Step 10**




**:: Bag 5 - Step 1**




Bag 5 - Step 2



Bag 5 - Step 3



Bag 5 - Step 4



**:: Bag 6 - Step 1**

91047 HD Ballstud, 6mm

25215 M3 locknut

91560 5x10x4mm bearing

91676 Caster Hat Bushings

Thick

Thin

Build x2  
(1 left side, 1 right side)

31532 x2 3x8mm BHCS

92376 Steering block arm, (kit setting)+2

92171 Steering blocks

32043 Axle crush tubes, 5.6mm

91567 5x12x4mm bearing

91047 HD Ballstud, 6mm

31382 Ballstud washer, 1mm

92535 B84 Caster block (left)

92522 B84 Caster inserts, "0"

89202 x2 3x12mm BHCS

**!**

There are three caster block inserts included (0°, +/- 1°, +/- 2°). 0° is the standard insert used.  
Tab up = adds caster  
Tab down = removes caster

**:: Bag 6 - Step 2**

91438 CVA barrel

92548 CVA bones, 78.5mm

91438 CVA pin

BLACK GREASE #6588

92191 Front CVA axle

92263 Front CVA retainer


**:: Bag 6 - Step 3**

91436 CVA wheel hex pin


91611 1.6x5mm SHCS

91609 FT clamping wheel hex, 5.0mm


Bag 6 - Step 4



Bag 7 - Step 1




Bag 7 - Step 2





Bag 7 - Step 3

Rear Axle Height			
	↓ 0	3 ↑	+3mm
	↓ 1	2 ↑	+2mm
	↑ 1	2 ↓	+1mm
	↑ 0	3 ↓	+0mm



**:: Bag 8 - Step 1**



**!** Orient the notch to the left throughout the car. It indicates which end has the left hand threads!





**!**  
Note:  
All turnbuckle inner measurements are approximate.



Build x2 (1 left side, 1 right side)


**:: Bag 8 - Step 2**



**!** Orient the notch to the left throughout the car. It indicates which end has the left hand threads!





**!**  
There is two offset ballcups labeled "1" and "2". The ballcup labeled "1" goes on the left side of the car.



Build x2 (1 left side, 1 right side)

**:: Bag 8 - Step 3**




Build x2 (1 left side, 1 right side)


**!** Orient the notch to the left throughout the car. It indicates which end has the left hand threads!




**:: Bag 9 - Step 1**




**:: Bag 9 - Step 2**



**:: Bag 9 - Step 3**



**:: Bag 10 - Step 1**



Note:  
The anti-roll bar rod end should be perpendicular to the suspension arm when assembled. This may require flipping the anti-roll bar pivot or adjusting it on the bar to achieve the correct setting depending on arm position.

**!**  
Note: Orient the set screws in the same location on left and right side.


Note: Leave some side to side movement when setting the anti-roll bar collars. The anti-roll bar should not bind the suspension

**92457 x2**  
Anti-roll bar collar




**31500 x4**  
3x2.5mm Set screw

**92458**  
Anti-Roll bar 1.3mm



**:: Bag 10 - Step 2**



Note:  
The anti-roll bar rod end should be perpendicular to the suspension arm when assembled. This may require flipping the anti-roll bar pivot or adjusting it on the bar to achieve the correct setting depending on arm position.

**!**  
Note: Orient the set screws in the same location on left and right side.


Note: Leave some side to side movement when setting the anti-roll bar collars. The anti-roll bar should not bind the suspension

**92457 x2**  
Anti-roll bar collar




**31500 x4**  
3x2.5mm Set screw

**92458**  
Anti-Roll bar 1.4mm



**:: Bag 11 - Step 1**




Build x2 front shocks

**!**  
Mount the shock pistons with the number facing up!




Racers Tip:

Use a marker over the numbers on the pistons to make them easily visible!



Build x2 rear shocks

Bag 11 - Step 2



91920  
13x23mm  
Shock bodies  
"front"

91493 x2  
X-Ring

91996  
13mm Shock  
spacer

91996 x2  
13mm Shock  
hat bushing

31327  
VCS3 Shock  
bottom cap

91996  
13mm  
Shock cap  
O-Ring

FT GREEN SLIME #1105




Lightly rub shock oil on the O-ring before installation!



Racers Tip:

Coating the O-rings with green slime (#1105) helps seal & reduce O-ring swell! Green slime not included in kit!



91996  
13mm  
Shock cap  
O-Ring

91922  
13x27.5mm  
Shock bodies  
"rear"

91493 x2  
X-Ring

91996  
13mm Shock  
spacer

91996 x2  
13mm Shock  
hat bushing


31327  
VCS3 Shock  
bottom cap

FT GREEN SLIME #1105

Build x2 front shocks

Build x2 rear shocks

Bag 11 - Step 3



4187  
Shock  
limiter  
(front - 2)  
(rear - 0)




Lightly rub shock fluid or green slime on threads



There are 3 lengths of shock eyelet in the kit. Pay attention to length when building as these affect your droop and uptravel.




0mm    +2mm    +4mm



4187  
Nylon  
spacer

92419  
Shock eyelets  
front shocks  
0 eye

91819  
Shock  
pivot ball




92419  
Shock Eyelets  
rear shocks  
+2 eye

91819  
Shock  
pivot ball

Build x2 front shocks

Build x2 rear shocks

Bag 11 - Step 4



Shock Fluids:  
Front Shock: 35wt  
Rear Shock: 30wt


91926  
13mm  
Shock cap

31510  
2x4mm  
BHCS

Steps 2-3    Steps 4-5    Steps 6-7    Step 8

**Shock Bleeding Steps:**

1. Before assembly, get each bleed screw and thread it 1-2 turns into the shock cap, then remove the screw. This will make it easier when you are bleeding your shocks.
2. Pull shock shaft down.
3. Fill shock body 3/4 full with silicone shock fluid.
4. Slowly move the shock shaft up and down to remove air from under the piston.
5. Wait for bubbles to come to surface.
6. Fill shock body to top with silicone shock fluid.
7. Place a drop of oil in the cap and on cap threads.
8. Install cap (without bleed screw) and tighten completely.
9. Slowly compress shaft all the way to bleed excess silicone shock fluid out the hole in the cap (use rag around shock to catch excess fluid).
10. Install M2x4mm button head screw until snug while shaft is fully compressed.



Stroke  
Front: 22mm  
Rear: 28mm

Steps 9-10

**Bag 11 - Step 5**

91996 x4  
13mm  
Threaded  
collar  
O-ring

91928 x4  
13mm  
Threaded  
collar

91944  
13mm Front  
spring, red  
(4.00lb)

91951  
13mm Rear  
spring, yellow  
(2.30lb)

Racers Tip:  
Use your finger to rub shock  
fluid on the O-ring for smoother  
adjustment!

Build x4

**Bag 11 - Step 6**

Set height  
after  
assembly

91926  
13mm Shock  
spring cup  
"front - 9mm"

#91966 13mm Shock Spring Cups  
0mm      5mm      9mm

91966  
13mm Shock  
spring cup  
"rear - 0mm"

Hold shock mounting  
hardware until after  
anti-roll bar installation.

Build x2 front shocks

Build x2 rear shocks

**Bag 11 - Step 7**


Install x2 front and x2 rear shocks

25612  
M3 flanged  
nut, black


25187  
M3x14mm  
BHCS

25612 x2  
M3 flanged  
nut, black


⚙️ Bag 12 - Step 1



⚙️ Bag 12 - Step 2



⚙️ Bag 12 - Step 3




**Bag 12 - Step 4**

31532 x2  
M3x8mm  
BHCS

92505  
B84  
Battery  
holder  
"3"

25201  
M3x8mm  
FHCS





Kit setting 4 5

**!**  
Use M3 x 20mm for  
standard height  
Use M3 x 14mm  
LP height


25188 x2  
M3x20mm  
BHCS

92505  
B84  
Battery  
holder

92463 x2  
Battery  
holder  
O-Ring



**Bag 12 - Step 5**



Battery  
(Not included)




**Bag 12 - Step 6**


Receiver  
(Not included)

ESC  
(Not included)


6727  
Servo tape




92424  
B7 wing



### Bag 12 - Step 7



### Bag 12 - Step 8



### Tuning Tips - Painting, Beginners

#### Painting:

Your Kit requires a clear polycarbonate body. You will need to prep the body before you can paint it. Wash the **INSIDE** thoroughly with warm water and liquid detergent (do not use any detergents with scents or added hand lotion ingredients!). Dry the body using a clean, soft, lint-free cloth. Use the supplied window masks to cover the windows from the **INSIDE** of the body (RC bodies get painted on the inside). Using high quality masking tape, apply tape to the inside of the body to create a design. Spray (use either rattle can or airbrush) the paint on the inside of the body (preferably dark colors first, lighter colors last). **NOTE: ONLY** use paint that is recommended for (polycarbonate) plastics. If you do not, you can destroy the body! After the paint has completely dried (usually after 24 hours), cut the body along the trim lines. Make sure to drill or use a body reamer to make the holes for the antenna if needed! Use hook and loop tape to secure the body to the side rails of the vehicle.


#### Tips for Beginners:

Before making any changes to the standard setup, make sure you can get around the track without crashing. Changes to your vehicle will not be beneficial if you can't stay on the track. Your goal is consistent laps. Once you can get around the track consistently, start tuning your vehicle. Make only **ONE** adjustment at a time, testing it before making another change. If the result of your adjustment is a faster lap, mark the change on the included setup sheet (make additional copies of the sheet before writing on it). If your adjustment results in a slower lap, revert back to the previous setup and try another change. When you are satisfied with your vehicle, fill in the setup sheet thoroughly and file it away. Use this as a guide for future track days or conditions. Periodically check all moving suspension parts. Suspension components must be kept clean and move freely without binding to prevent poor and/or inconsistent handling.

## ⚙️ Tuning Tips - Front Arm Mount Pill Insert Setups


### Standard Position

Use this position as a reference when changing pill locations.




Kick-up: 10°  
Roll Center: +0  
Pin Width: +0

### Possible Insert Locations



### Insert Hole Locations



The aluminum front arm mounts utilize eccentric pill inserts to make fine adjustments to kick-up, pin height, and pin width. Adjustments can be made using the supplied inserts (#92014)

**Pin Width**  
More distance = wider pivot  
Less distance = narrower pivot

A Mount	B Mount	
		= +1.4mm
		= +0.7mm
		= 0mm
		= -0.7mm
		= -1.4mm

**Pin Height**  
Higher pin = Higher roll center  
Lower Pin = Lower roll center

A Mount	B Mount	
		= +0.7mm
		= +0.35mm
		= 0mm
		= -0.35mm
		= -0.7mm

### Kick Up


More angle = More kick up  
Less angle = Less kick up



A Mount	B Mount	
		= 10°
		= 9°
		= 8°
		= 11°
		= 10°
		= 9°
		= 12°
		= 11°
		= 10°

### Total Caster Angle

Total caster angle is the sum of the kick up angle and the caster block angle.




Caster Block Angle	Kick Up Angle			
	8°	9°	10°	11°
6°	14°	15°	16°	17°
7°	15°	16°	17°	18°
8°	16°	17°	18°	19°
9°	17°	18°	19°	20°
10°	18°	19°	20°	21°

## ⚙️ Tuning Tips - Rear Arm Mount Pill Insert Setups


### Standard Position

Use this position as a reference when changing pill locations.




Toe: 3°  
Anti-Squat: 2°  
Roll Center: +0  
Pin Width: +0

### Possible Insert Locations



### Insert Hole Locations



The aluminum front arm mounts utilize eccentric pill inserts to make fine adjustments to kick-up, pin height, and pin width. Adjustments can be made using the supplied inserts (#92014)

**Pin Width**  
More distance = wider pivot  
Less distance = narrower pivot


C Mount	D Mount	
		= +1.4mm
		= +0.7mm
		= 0mm
		= -0.7mm
		= -1.4mm

**Pin Height**  
Higher pin = Higher roll center  
Lower Pin = Lower roll center

C Mount	D Mount	
		= +0.7mm
		= +0.35mm
		= 0mm
		= -0.35mm
		= -0.7mm

### Anti-Squat Angle


More angle = More anti-squat  
Less angle = Less anti-squat



C Mount	D Mount	
		= 2°
		= 1°
		= 0°
		= 3°
		= 2°
		= 1°
		= 4°
		= 3°
		= 2°

### Toe Angle

More angle = More toe in  
Less angle = Less toe in  
Shown in 1° changes



C Mount	D Mount	
		= 3°
		= 4°
		= 5°
		= 2°
		= 3°
		= 4°
		= 1°
		= 2°
		= 3°

## Front Suspension:

Ride Height: **17mm**

Camber: **-1 deg**

Toe: **0 deg**

Anti-Roll Bar: **1.3mm**

Arm Type: **Kit**

Tower Type: **Kit**

Wheelbase Shim: **Arm Middle**

Wheel Hex: **5mm**

Steering Block Type: **B74**

Caster Block: 6°  7°  8°  9°  10°

Chassis Brace Material: **Kit**

Top Plate Brace Material: **Kit**

Front Axles: CVA  DCV

Notes:

Lower Brace Type: Fixed  Pivot



Ball Stud Spacing: **2mm**


Arm Mount A: 1°  0.5°   
 Gray  Black



Arm Mount B: 1°  0.5°   
 Gray  Black



Diff Height:  
 +3   
 +2   
 +1   
 +0



## Rear Suspension:

Ride Height: **17mm**

Camber: **-1 deg**

Anti-Roll Bar: **1.4mm**

Arm Type: **Kit - B7**

Tower Type: **Kit**

Wheelbase Shim: **Arm Middle**

Wheel Hex: **6mm**

Hub Type: **Kit - B7 Standard**

Drive Shaft Type: **69mm Bone**

Chassis Brace Material: **Kit**

Upper Chassis Brace Material:

Hub Spacing: Fwd  Mid  Back

Notes:

Lower Brace Type: Fixed  Pivot



Rear Chassis Brace Screws:

Arm Mount C: 1°  0.5°   
 Gray  Black




Arm Mount D: 1°  0.5°   
 Gray  Black



Axle Height:  
 ▼0 3▲ +3  
 ▼1 2▲ +2  
 ▲1 2▼ +1  
 ▲0 3▼ +0

Diff Height:  
 +3   
 +2   
 +1   
 +0



## Electronics:

Radio: \_\_\_\_\_ Servo: \_\_\_\_\_

EPA: Throttle: \_\_\_\_\_ % Brake: \_\_\_\_\_ %

ESC: \_\_\_\_\_

ESC Settings: \_\_\_\_\_

Motor / Wind: \_\_\_\_\_ Timing: \_\_\_\_\_

Pinion: \_\_\_\_\_ Spur: \_\_\_\_\_

Motor Position: Forward:  Back:

Battery Position:  
 Back 1  2  3  4  5  Forward

Battery: \_\_\_\_\_ Weight: \_\_\_\_\_

Notes:

## Differential:

	Front	Center	Rear
Fluid:	15K	200K	15K
Gears:	LTC	LTC	LTC
Type:	Plastic	Plastic	Plastic

Notes:

## Slipper Clutch:

Type: \_\_\_\_\_

# of Pads: \_\_\_\_\_

Setting: \_\_\_\_\_

Notes:

## Shocks:

	Front	Rear
Piston:	2x1.7	2x1.9
Thickness:	2.5mm	2.5mm
Fluid:	35wt	30wt
Spring:	Red	Yellow
Limiters: Int: <u>2</u> Ext: <u>1</u> Int: <u>0</u> Ext: <u>0</u>		
Stroke:	22mm	28mm
Eyelet:	0	+2
Cup Offset: 0 <input type="checkbox"/> +5 <input type="checkbox"/> +9 <input checked="" type="checkbox"/> 0 <input checked="" type="checkbox"/> +5 <input type="checkbox"/> +9 <input type="checkbox"/>		
Kashima Bodies: <input type="checkbox"/> Chrome Shafts: <input type="checkbox"/> Machined Spacers: <input type="checkbox"/>		

Notes:



## Track Info:

Size: \_\_\_\_\_

Surface: \_\_\_\_\_

Traction: \_\_\_\_\_

Moisture: \_\_\_\_\_

Condition: \_\_\_\_\_

Temperature: \_\_\_\_\_

Notes:

## Tires:

Front Tires: \_\_\_\_\_

Front Compound: \_\_\_\_\_

Front Insert: \_\_\_\_\_

Rear Tires: \_\_\_\_\_

Rear Compound: \_\_\_\_\_

Rear Insert: \_\_\_\_\_

Wheel (F/R): \_\_\_\_\_

Notes:

## Body, Weight:

Body: **B84**

Front Wing: **Nose**

Rear Wing: **B7**

Rear Wing Mount: 0  -2

Wing Angle: 0°  3°  6°

Chassis Length: **Standard**

Total Vehicle Weight: \_\_\_\_\_

Notes:

## Vehicle Comments:

Notes:

## Front Suspension:

Ride Height: \_\_\_\_\_  
 Camber: \_\_\_\_\_  
 Toe: \_\_\_\_\_  
 Anti-Roll Bar: \_\_\_\_\_  
 Arm Type: \_\_\_\_\_  
 Tower Type: \_\_\_\_\_  
 Wheelbase Shim: \_\_\_\_\_  
 Wheel Hex: \_\_\_\_\_  
 Steering Block Type: \_\_\_\_\_  
 Caster Block: 6°  7°  8°  9°  10°   
 Chassis Brace Material: \_\_\_\_\_  
 Top Plate Brace Material: \_\_\_\_\_  
 Front Axles: CVA  DCV   
 Notes: \_\_\_\_\_

Lower Brace Type: Fixed  Pivot



Ball Stud Spacing: \_\_\_\_\_


Arm Mount A: 1°  0.5°   
 Gray  Black



Arm Mount B: 1°  0.5°   
 Gray  Black



Diff Height:  
 +3   
 +2   
 +1   
 +0



## Rear Suspension:

Ride Height: \_\_\_\_\_  
 Camber: \_\_\_\_\_  
 Anti-Roll Bar: \_\_\_\_\_  
 Arm Type: \_\_\_\_\_  
 Tower Type: \_\_\_\_\_  
 Wheelbase Shim: \_\_\_\_\_  
 Wheel Hex: \_\_\_\_\_  
 Hub Type: \_\_\_\_\_  
 Drive Shaft Type: \_\_\_\_\_  
 Chassis Brace Material: \_\_\_\_\_  
 Upper Chassis Brace Material: \_\_\_\_\_  
 Hub Spacing: Fwd  Mid  Back   
 Notes: \_\_\_\_\_

Lower Brace Type: Fixed  Pivot



Rear Chassis Brace Screws: \_\_\_\_\_

Arm Mount C: 1°  0.5°   
 Gray  Black




Arm Mount D: 1°  0.5°   
 Gray  Black



Axle Height:  
 ▼0 3▲ +3  
 ▼1 2▲ +2  
 ▲1 2▼ +1  
 ▲0 3▼ +0

Diff Height:  
 +3   
 +2   
 +1   
 +0



## Electronics:

Radio: \_\_\_\_\_ Servo: \_\_\_\_\_  
 EPA: Throttle: \_\_\_\_\_ % Brake: \_\_\_\_\_ %  
 ESC: \_\_\_\_\_  
 ESC Settings: \_\_\_\_\_  
 Motor / Wind: \_\_\_\_\_ Timing: \_\_\_\_\_  
 Pinion: \_\_\_\_\_ Spur: \_\_\_\_\_  
 Motor Position: Forward:  Back:   
 Battery Position:  
 Back 1  2  3  4  5  Forward  
 Battery: \_\_\_\_\_ Weight: \_\_\_\_\_  
 Notes: \_\_\_\_\_

## Differential:

	Front	Center	Rear
Fluid:	_____	_____	_____
Gears:	_____	_____	_____
Type:	_____	_____	_____

Notes: \_\_\_\_\_

## Slipper Clutch:

Type: \_\_\_\_\_  
 # of Pads: \_\_\_\_\_  
 Setting: \_\_\_\_\_  
 Notes: \_\_\_\_\_

## Shocks:

	Front	Rear
Piston:	_____	_____
Thickness:	_____	_____
Fluid:	_____	_____
Spring:	_____	_____
Limiters: Int: _____ Ext: _____ Int: _____ Ext: _____		
Stroke:	_____	_____
Eyelet:	_____	_____
Cup Offset: 0 <input type="checkbox"/> +5 <input type="checkbox"/> +9 <input type="checkbox"/> 0 <input type="checkbox"/> +5 <input type="checkbox"/> +9 <input type="checkbox"/>		
Kashima Bodies: <input type="checkbox"/> Chrome Shafts: <input type="checkbox"/> Machined Spacers: <input type="checkbox"/>		

Notes: \_\_\_\_\_

## Track Info:

Size: \_\_\_\_\_  
 Surface: \_\_\_\_\_  
 Traction: \_\_\_\_\_  
 Moisture: \_\_\_\_\_  
 Condition: \_\_\_\_\_  
 Temperature: \_\_\_\_\_  
 Notes: \_\_\_\_\_

## Tires:

Front Tires: \_\_\_\_\_  
 Front Compound: \_\_\_\_\_  
 Front Insert: \_\_\_\_\_  
 Rear Tires: \_\_\_\_\_  
 Rear Compound: \_\_\_\_\_  
 Rear Insert: \_\_\_\_\_  
 Wheel (F/R): \_\_\_\_\_  
 Notes: \_\_\_\_\_

## Body, Weight:

Body: \_\_\_\_\_  
 Front Wing: \_\_\_\_\_  
 Rear Wing: \_\_\_\_\_  
 Rear Wing Mount: 0  -2   
 Wing Angle: 0°  3°  6°   
 Chassis Length: \_\_\_\_\_  
 Total Vehicle Weight: \_\_\_\_\_  
 Notes: \_\_\_\_\_

## Vehicle Comments:

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_



**Associated Electrics, Inc.**  
**21062 Bake Parkway Lake Forest, CA 92630 USA**

**call: (949) 544-7500 - fax: (949) 544-7501**  
**Check out the following web sites for all of our kits, current products,**  
**new releases, setup help, tips, and racing info!**  
**[www.AssociatedElectrics.com](http://www.AssociatedElectrics.com)**

**FOLLOW US ON SOCIAL MEDIA**



TeamAssociated  
ReedyPower  
ElementRC  
FactoryTeam51



@TeamAssociatedRC  
@ReedyPower  
@Element\_RC  
@FactoryTeam\_RC



@Team\_Associated  
@ReedyPower



@Associated\_Electrics



TeamAssociatedRC  
ElementRC



TeamAssociated  
Reedy  
Element-rc