

#3963 FACTORY TEAM THREADED SHOCK KIT

1 Slide one black O-ring into the groove in the threaded shock collar.



2 Use one drop of oil on the O-ring before you thread on the shock collar.



3 Carefully thread on the shock collar. Make sure that the shoulder is facing down when threaded on the body.

shoulder faces down



TEAM ASSOCIATED



web: <http://www.teamassociated.com>